Operating Instruction

Desktop Vacuum Cleaner

Battery Model



Operating Method



1.Turn the switch on and turn if off again.



2. The battery into the battery slot, ready to work.

Cleaning Method



1.Open the rear cover according to the direction which shown on picture after shut off power supply switch.



2.Drop the scraps which from rear cover and machine into garbage can.

Note: need clean the scraps of rear cover.



Tightly blocked and reset

3.Box cover reset after tightly blocked the rear cover according to the arrow direction.

Product Maintenance Method



Note:
Remove the filter and clean it with a brush. Please don't use water spraying wash the filter. Avoiding water enter into machine and caused damage.

Warmly Reminding

1.Please don't make fingers deep in dust adsorption mouth;
2.Please don't freely disassemble or modify this machine;
3.This product used to clean the thin and small pellets like rubber scraps, keyboard dust, paper scraps on table, please don't used to clean the bigger stones and liquids avoid affect operation.

Retrieve

Please must put the wasted electric products into appointed area. Environment protection, everybody is in responsible.

Product Structure and Name



1	Up cover	5	Down cover
2	Battery case	6	Down cover brush hair
3	ON/OFF	7	Vane
4	Middle shell	8	Dustproof net

Maintain Guarantee Card

Hello, dear customers! Thanks for you purchase products, this product produced under the strict quality control and quality test. This maintain guarantee card means that when occur failure under the normal operating situation, provide maintenance and adjustment to customer according to the stipulates in this maintain guarantee card.

1.From the day of purchased, can get 1 year maintain guarantee service only when happen failure under normal operating, but damages caused by the human damage(example incorrect manually disassemble the parts and handle damages, etc), naturally damaged(example fire, earthquake, flood, rat damage, etc) are not in maintain guarantee scope.

2.Consume parts(example batteries, etc) and renewal accessories are not belong to the maintain guarantee scope of this maintain guarantee card.

3.Not reissue once loss this maintain guarantee card, please must keep well.

4.Not provide free maintain guarantee service because the failure by customers.

5.Product happen failure when it's maintain guarantee period expired, if our company still has the accessories then provide maintain guarantee service with certain part fees and management fees.

6.This maintain guarantee card only valid in the local of the People's Republic of China.

Instruction:please keep this maintain guarantee card with invoice for check when future maintaining.

Product Name	
Maintain Guara -ntee Period	Valid within 1 year from the day of purchased, date:
Produce Serial Number:	
1.Customer Information:	
Customer Name:	
Customer Address:	
Phone Number:	Postal Code:
2.Distributor Information:	
Company Name:	
Company Address:	
Phone Number:	Postal Code:

Product Parameter

Product Name	Desktop Vaccum Cleaner
Main Material	ABS
Battery	2*AA
Battery Voltage	3V
Working Time	It depends on the specific battery

Produce date:

Keep for reserve use

Interior contain small parts, not suitable to be used by the children under age 3, carefully prevent swallowed by children.